



INSTALLATION INSTRUCTIONS:

1. REMOVE BACK PLATE (ITEM 1 ABOVE) BY UNSCREWING IT FROM THE BODY.
2. DRILL HOLE FOR PLASTIC BANTAM (SUPPLIED) WHEN LOCATION FOR BUMPER IS IDENTIFIED. USE A $\varnothing 1/4$ INCH DRILL BIT. INSERT BANTAM.
3. MOUNT BACK PLATE LOOSELY AND MARK SPOT FOR NAIL (SHOULD BE 1/4 INCH OVER FROM CENTER HOLE). REMOVE BACK PLATE.
4. DRILL HOLE FOR NAIL USING 3/32 INCH DRILL BIT
5. REINSTALL BACK PLATE WITH SCREW (#6 X 1/2" FH PH WS) - SECURE TIGHTLY, INSERT AND DRIVE NAIL (#16 X 5/8" PIN) INTO BACK PLATE HOLE DRILLED FOR NAIL
6. SCREW BODY OVER BACK PLATE - MAKE SURE BUMPER IS INSERTED INTO BODY PRIOR TO INSTALLATION.