



SUPPLIED WITH: TWO (2) 1/4-20 X 7/8 ANCHOR, TWO (2) #14 X 1-1/4 PLASTIC BANTAMS, TWO (2) #14 X 1-1/2 FLAT HEAD, PHILLIPS DRIVE WOOD SCREWS, TWO (2) 1/4-20 X 1 UNDERCUT FLAT HEAD, PHILLIPS DRIVE MACHINE SCREWS AND TWO (2) 1/4-20 X 1 FLAT HEAD, TORX DRIVE MACHINE SCREWS.

WHEN INSTALLING USING THE ANCHOR, DRILL PREP Ø1/2" HOLE X 7/8" DEEP, WHEN USING THE PLASTIC BANTAM DRILL PREP Ø1/4" X 1-1/4 DEEP.