



# FOR WOOD AND METAL DOORS

INTERIOR  
SIDE

TOP OF DOOR  
SHOWING PREP



FRONT OF DOOR EDGE  
SHOWING PREP



## RIGHT HAND DOOR

NOTE: This template is provided for use only on the job for which it was requested. Trimco reserves the right to make design changes without notice. Trimco will not be responsible for errors or damage caused by the use of out-of-date templates.

Revised 02/15/15  
SHEETS 1 AND 2: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 3 AND 4: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 5 AND 6: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 7 AND 8: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 9 AND 10: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 11 AND 12: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 13 AND 14: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 15 AND 16: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 17 AND 18: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 19 AND 20: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 21 AND 22: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 23 AND 24: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 25 AND 26: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 27 AND 28: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 29 AND 30: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 31 AND 32: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 33 AND 34: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 35 AND 36: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 37 AND 38: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 39 AND 40: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 41 AND 42: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 43 AND 44: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 45 AND 46: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 47 AND 48: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 49 AND 50: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 51 AND 52: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 53 AND 54: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 55 AND 56: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 57 AND 58: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 59 AND 60: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 61 AND 62: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 63 AND 64: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 65 AND 66: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 67 AND 68: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 69 AND 70: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 71 AND 72: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 73 AND 74: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 75 AND 76: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 77 AND 78: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 79 AND 80: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 81 AND 82: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 83 AND 84: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 85 AND 86: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 87 AND 88: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 89 AND 90: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 91 AND 92: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 93 AND 94: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 95 AND 96: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 97 AND 98: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS  
SHEETS 99 AND 100: LOCKSET AND INDICATOR MOUNTING SCREWS, 2 PLCS

DATE  
11/02/15

TEMPLATE NO.  
19490  
SHT 1 OF 5

**Trimco**  
3528 Emery Street  
PO BOX 23277  
Los Angeles, CA 90023-0277  
(323) 262-4191 www.trimcobdw.com  
email: info@trimcobdw.com

PRODUCT  
1074-2-XXX-5004  
POCKET/BARN DOOR W/ LOCK INDICATOR  
INSTALLATION SHEETS  
MORTISE LOCK PREP




**Trimco**


3528 Emery Street  
PO BOX 23277  
Los Angeles, CA 90023-0277  
(323)262-4191 www.trimcobw.com  
email: info@trimcobw.com

1074-2-XXX-5004  
POCKET/BARN DOOR W/ LOCK INDICATOR  
INSTALLATION SHEETS  
MORTISE LOCK PREP

# FOR WOOD AND METAL DOORS



FRONT OF DOOR EDGE SHOWING PREP



# LEFT HAND DOOR

NOTE: This template is provided for use only on the job for which it was requested. Trimco reserves the right to make design changes without notice. Trimco will not be responsible for errors or damage caused by the use of out-of-date templates.

DATE  
11/02/15




**Trimco**



3528 Emery Street  
PO BOX 23277  
Los Angeles, CA 90023-0277  
(323)262-4191 www.trimcobw.com  
email: info@trimcobw.com

1074-2-XXX-5004  
POCKET/BARN DOOR W/ LOCK INDICATOR  
INSTALLATION SHEETS  
MORTISE LOCK PREP

# WOOD DOOR PREP



# WOOD FRAME PREP



1072-2 STRIKE/DUST COVER ASSEMBLY


NOTE: This template is provided for use only on the job for which it was requested. Trimco reserves the right to make design changes without notice. Trimco will not be responsible for errors or damage caused by the use of out-of-date templates.

DATE  
11/02/15



# METAL FRAME PREP

# DOOR PREP




FRAME:  
FACING FRONT

FRAME:  
FACING SIDE

THIS FRAME PREP IS FOR  
SURFACE-MOUNTED STRIKES

DOOR:  
FACING SIDE



1072-2 STRIKE/DUST COVER ASSEMBLY

NOTE 1:

IF THE STRIKE IS SURFACE MOUNTED, THERE WILL BE A GAP BETWEEN THE FRAME AND THE DOOR.

NOTE 2:

IF THE STRIKE IS TO BE FLUSH MOUNTED, REFER TO SHEET 3 FOR FRAME PREP SPECIFICATIONS.

NOTE: This template is provided for use only on the job for which it was requested. Trimco reserves the right to make design changes without notice. Trimco will not be responsible for errors or damage caused by the use of out-of-date templates.

DATE  
11/02/15

**INSTALLATIONS STEPS****1074-2-XXX-5004****POCKET DOOR PRIVACY SET WITH LOCK INDICATOR  
WITH LEVERS IN THE DOWN POSITION**

1. After the door and frame have been prepped, take the mortise lock, remove the front cover plate, and temporarily set the plate and the two mounting screws aside.
2. Insert the mortise lock into the prep on the door's edge. Using a screwdriver, screw in both of the #12 x 1" flat head combination screws into each pinhole located at the top and bottom.
3. Install the strike/dust box assembly into the frame using the two #12 x 1" flat head combination screws supplied for this purpose.
4. Install two 3/8" adaptor screws on each side into the mortise lock shown on template #19539 and install (2) 1/4" adaptor screws on the interior side, again, as shown on template #19539.
5. Take one lever assembly and insert into the exterior door prep, you will have to make sure that the lever spindle is inserted into the spindle hub; while you are doing this, push the lever assembly against the door's surface. The lever should be at the down position. Install the two mounting screws.
6. Take the other lever assembly into the door prep on the interior side; you will have to make sure that the lever spindle is inserted into the spindle hub; while you are doing this, push the lever assembly against the door's surface. The lever should be in the down position. Install the two mounting screws.
7. Install the thumb-turn assembly on the interior side, with the thumb-turn in the up position (12 o'clock) and the deadbolt retracted: insert the thumb-turn spindle into the hub, then install the mounting screws shown on template #19539.
8. Test the lever set by throwing the thumb-turn towards the strike. This should extend the latch forward and therein lock the door on the outside. Grab the exterior lever to make sure that it is rigid (locked).
9. Now test the interior lever. First, close the door all the way to the strike, then; turn the thumb-turn towards the strike. This will extend the latch bolt into the strike and lock the door to the outside. Next pull on the interior lever to open the door; you should be able to see the thumb-turn move back while you are operating the lever and consequently opening the door.
10. Hold the cylinder and check to see if the "wave washer" spring is behind the cylinder face. Taking the cylinder collar, insert the cylinder into the collar, making sure that the "wave washer" spring is between the collar and behind the cylinder head. Make sure that the plug cylinder is on the other side.
11. Thread the cylinder and the cylinder collar into the exterior side of the mortise lock- keep threading until the cylinder collar is no longer moving. Make sure that the keyway is at the 6 o'clock position.
12. Take a screwdriver and insert it into the hole that is just above the latch bolt. There is a setscrew in this hole that needs to be tightened- do not over tighten, make sure to line-up the notches on the cylinder and on the plug.
13. Now test the cylinder- insert the key and verify that turning the key moves the latch bolt back and forth smoothly. Turning the key should also rotate the thumb-turn.
14. To conclude the installation, open the door (if it is not already open), and retract the latch bolt either by rotating the key or the thumb-turn. Locate the mortise lock faceplate and the two mounting screws that were set aside at the start of this installation and re-install the faceplate using these two screws.
15. Conduct a final check to verify satisfactory performance using the key, the levers, and the thumb-turn.
16. On both sides of the door: navigate the roses (cover plates) about the levers- you will need to draw them upwards, then rotate them 90 degrees at the bend in lever-then snap them into place(no fasteners required).
17. Install the lock indicator (5004) reference Template 17402, using the 3 mounting screws provided. Make sure, that the INDICATOR is in the OPEN position, while installing, (the green color should be displayed).
18. Peel away the back of the "SLIDE" decal and adhere to the door as is shown in Template 19539 Installation Instructions.
19. The installation is complete.

NOTE: This template is provided for use only on the job for which it was requested.

Trimco reserves the right to make design changes without notice. Trimco will not be responsible for errors or damage caused by the use of out-of-date templates.

DATE

11/02/15