
















TEMPLATE NO.		TRIMCO TECHNICAL PUBLICATION		PRODUCT		
DRAWING 20326 BARN DOOR STRIKE SHEET 1 OF 2		1351 Rocky Point Drive Oceanside, CA. 92056 323.262.4191		BARN DOOR STRIKE U.S. PATENT APPLIED FOR		
REVISION 01		REV DATE: 12/04/18		ENGINEER: C. ODOM		
				CREATED DATE: 12/04/18		
INSTALLATION GUIDE				TOOLS NEEDED		
READ INSTALLATION GUIDE IN ITS ENTIRETY TO ENSURE ACCURACY OF INSTALL.				<div></div> <div>NO. 2 PHILLIPS SCREWDRIVER</div> <div></div> <div>NO. 3 PHILLIPS SCREWDRIVER</div>		
PARTS LIST						
<div></div> <div>TEMPLATE</div>	<div></div> <div>MOUNTING SCREWS</div>	<div></div> <div>WITH RETURN MOUNTING BRACKET</div>	<div></div> <div>DIRECT MOUNT</div>	<div></div> <div>BASE</div>	<div></div> <div>STRIKE & SHIMS</div>	<div></div> <div>CAP & SET SCREW</div>
Always refer to trimcohardware.com for the latest version.This document and it's content is the property of Trimco Hardware.						
1 TO INSTALL MOUNTING BRACKET: BOTH JAMB AND DIRECT MOUNT.						
<div></div> <div>USE TEMPLATE TO DRILL PILOT HOLES FOR MOUNTING SCREWS. ALIGN TEMPLATE CENTERLINE WITH CENTER OF DEADBOLT AND EDGE OF DOOR FRAME.</div> <div>JAMB MOUNT USES FIVE SCREWS (ONE IN DOOR JAMB) DIRECT MOUNT USES FOUR SCREW.</div>						
2 TO INSTALL CAP BRACKET:						
<div><div>NOTE: VERTICAL ADJUSTABILITY ("1 SLIDE")</div><div></div><div>INSTALL CAP BRACKET TO MOUNTING BRACKET</div><div></div><div>MOUNTING BRACKET INSTALLED, DO NOT TIGHTEN SCREWS YET.</div><div><div>OFFSET STRIKE OPENING.</div><div></div><div>TEMPORARILY INSTALL THE SHIM AND STRIKE</div><div></div><div>NOTE: STRIKE IS OFFSET AND REVERSIBLE FOR BEST FIT. MAKE VERTICAL ADJUSTMENT IF NEEDED AND TIGHTEN SCREWS. (REMOVE SHIM AND STRIKE BEFORE NEXT STEP)</div></div></div>						
Always refer to trimcohardware.com for the latest version.This document and it's content is the property of Trimco Hardware.						

3


INSTALL CAP, TIGHTEN SET SCREW INTO DIVOT IN THE BACK OF THE BASE. (USE 3/32 HEX WRENCH)
NOTE: INSTALLATION OF THE SHIMS AND STRIKES COMPLETES THE ASSEMBLY/RETENTION OF THE CAP.



4

(TUBULAR) INSTALL SHIMS AND STRIKE
OPEN SIDE OF SHIMS FACES OUTWARD.

(MORTISE) INSTALL SHIM AND STRIKE
OPEN SIDE OF SHIM FACES OUTWARD.
STRIKE OPENING IS OFFSET AND REVERSABLE FOR BEST FIT.



5

IMPORTANT: SET BARN DOOR RAIL STOP.
CLOSE DOOR AND ADJUST STOP.
ADJUSTMENT CAN VARY WITH RUBBER
STOP DENSITY.

