

HOW TO CLEAN

Healthy HARDWARE®

BY TRIMCO



CLEANING

Although Healthy Hardware is made from copper alloy, this does not substitute for standard cleaning practices.

Healthy Hardware® can be cleaned by applying mild soap and water with a soft clean towel to wipe the surface. The surface should be completely dry before it is used again.



SANITIZING

Recommended sanitizing of products to clean Healthy Hardware® are:

1. Virex® II (Ammonium based cleaner), 10 min contact time, label directions state "Wipe Surfaces and let air dry"
2. Isopropyl Alcohol Wipes 70%, 15 sec contact time, no label direction for disinfecting hard surfaces
3. Clorox Healthcare™ Hydrogen Peroxide Cleaner Disinfectant Wipes, 5 min contact time, label directions state "Let air dry."



RESTORING

Healthy Hardware® Copper Nickel Alloys are a living finish, and will naturally patina over time.

In order to restore Healthy Hardware® to its original shine, we recommend using Wright's Copper Cream.

Wright's Copper Cream Directions State: "Wear rubber gloves. Rinse Copper in warm water. Rub directly onto copper using the enclosed sponge or clean cloth. Rinse with water, then dry and buff using a clean, soft cloth."

For the most up-to-date information about Healthy Hardware®, visit www.HealthyHardware.com.