














WOOD DOOR AND WOOD FRAME PREPARATION/TEMPLATE INSTRUCTIONS (METAL DOORS/METAL FRAMES SHOULD BE PRE-PREPARED)

<p>1 MARK DOOR HEIGHT</p>  <p>Draw a horizontal line on both sides of the door to indicate desired height of lever, (45" above floor suggested unless otherwise directed).</p>	<p>2 POSITION TEMPLATE</p>  <p>Fold (or cut if desired) enclosed latch template on dotted line. Align the line just marked on the door with the latch centerline which is on the latch/lever assy template. Tape template to door.</p>	<p>3 MARK DOOR</p>  <p>Mark appropriate drill points on door to correspond with points on latch/lever assy template.</p>	<p>4 DRILL EDGE BORES</p>  <p>Using mortise tool and a 1" bit, mortise for latch to depth of bore.</p>	<p>5 DRILL FACE BORES</p>  <p>Using a 2 1/8" dia hole saw drill through at point 1. Using 5/16" dia drill bit drill through at point 2 (4 places). Using 1" dia hole saw drill latchbolt hole to a depth of 4 3/8" for 2 3/4" backset, or 6 5/8" for 5" backset.</p>	<p>6 MORTISE AND POSITION FACEPLATE</p>  <p>Slide latch into mortise. Check that screw mounting points are centered before tracing the outline of the faceplate. Chisel for faceplate to a depth of 5/32".</p>	<p>7 PREPARE FRAME</p>  <p>Tape strike template at matching centerline to latch template. Mark hole centers. Position strike over frame and trace outline. Chisel to a depth of 3/32" to accommodate strike plate.</p>
--	--	---	--	--	--	--

INSTALLATION INSTRUCTIONS

<p>1 INSTALL LATCH</p>  <p>Place latch bolt unit in door, Making sure bolt bevel faces direction of door closing. Attach front with 2 (two) #8 screws.</p>	<p>2 INSTALL STRIKE</p>  <p>Install strike and strike box (if customer supplied) using two (2) #8 screws.</p>	<p>3 INSTALL LEVER ASSEMBLIES (SHOWN FOR 1562AP)</p>  <p>Install lever assemblies by aligning the mounting holes of the inside lever assembly with the corresponding holes in the door, by inserting the finger into the latch cutout, and inserting the locating pin in the corresponding hole in the latch. Verify handing for each assembly before mounting. Align lever assemblies and fasten with four (4) 10-24 mounting screws, four (4) external lock washers and four (4) hex nuts.</p> <p>LEFT HAND REVERSE SHOWN</p>	<p>4 INSTALL COVERS</p>  <p>Install covers and fasten with 6-32 screws.</p>
--	---	---	---

NOTE: This template is provided for use only on the job for which it was requested. Trimco reserves the right to make design changes without notice. Trimco will not be responsible for errors or damage caused by the use of out-of-date templates.

REVISION RECORD:
ADDED NEW STEP 2 FOR INSTALLATION INSTRUCTIONS, CORRECTED NEW STEP 3,
ADDED "3852 'C' STRIKE SHOWN" TO STEP 7 OF DOOR AND FRAME PREP, SGH/JG, 05/26/15
ADDED NEW STEP 2 FOR INSTALLATION INSTRUCTIONS, CORRECTED NEW STEP 3,
CORRECTED VIEWS TITLES AND INSTRUCTIONS, SGH/JG, 06/03/15
MODIFIED STEPS 1, 2 & 3 OF WOOD AND METAL DOOR PREPARATION INSTRUCTIONS, SGH/JG, 07/02/15
CHANGED TEXT IN STEP 4 OF WOOD AND FRAME PREP INSTRUCTIONS, CHANGED TEXT IN STEP 2 OF INSTALLATION INSTRUCTIONS, SGH/JG, 09/08/15

DATE

09/08/15